


Disney: ELECTRONICS

User's Guide  
ICE SHAVER





## QUICK REFERENCE



# IMPORTANT SAFEGUARDS

**WARNING: This Ice Shaver is not a toy. Close adult supervision is necessary when used by or near children. Please do not leave this unit unattended with children.**

When using electrical appliances, basic safety precautions should always be followed including:

- **Close supervision is required when any appliance is used by or near children.**
- Read all instructions before using.
- After running motor continuously for three minutes, wait at least five minutes before running the motor again.
- Do not use the appliance for anything other than its intended use.
- Do not operate this appliance with a damaged cord or plug, after the appliance malfunctions, or if the appliance is dropped or damaged in any manner. If you experience any problems with this machine, unplug it immediately and call Back To Basics at 1-800-688-1989.
- To protect against the risk of electrical shock, never immerse the cord, plug or the motor assembly in water or other liquid.
- The use of accessory attachments not recommended or sold by Back to Basics® may cause fire, electric shock or injury.
- This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.
- Do not use outdoors.
- Do not allow the cord to hang over the edge of a table or counter top.
- Do not let the cord come into contact with hot surfaces, including a stove.

# IMPORTANT SAFEGUARDS

- To disconnect, grip plug and pull from wall outlet. Never pull on cord to disconnect.
- Always unplug appliance from power supply before putting on or taking off parts, when cleaning and before cleaning.
- Be sure the appliance is in the OFF position after each use.
- Never leave the house while the appliance is ON.
- Extension cords may be used if care is exercised in their use. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. The extension cord should be arranged so that it will not drape over the counter top where it can be tripped over or pulled by children.
- Avoid contact with moving parts.
- Never place fingers or other utensils into feed or discharge areas.
- Check ice hopper for presence of foreign objects before using.
- The blade on the shaver bowl is sharp. Handle carefully.
- This machine is for household use only. Do not use continuously for more than 5 minutes at a time.
- Operate the appliance on a flat, clean surface.
- Make certain that the LID is securely locked in place before operating the ice shaver. Do not attempt to defeat the LID safety interlock mechanism.

## **IMPORTANT:**

**This unit has been designed with a special safety switch. Please note that the unit will not operate without the LID properly locked onto the MOTOR BASE.**

# IMPORTANT SAFEGUARDS

**SAVE THESE  
INSTRUCTIONS.**

**INTENDED FOR  
HOUSEHOLD USE  
ONLY.**

## OPERATION

### USING YOUR DISNEY ICE SHAVER

Before using for the first time and after each use, be sure to thoroughly wash the lid, secure nut, ice auger, cone holder, flavor bottle holders, gear ring and cone shaper in hot soapy water. To prolong the life of your Ice Shaver, do not wash parts in the dishwasher.

If you experience any problem with your machine, unplug it immediately from the electrical outlet, then contact Back to Basics® at 1.801.571.7349.

## OPERATION

1. When assembling, dismantling or cleaning, always ensure that the appliance is switched off and is not connected to the power supply.
2. Make sure that the GEAR RING is properly positioned around the exterior of the ICE AUGER.
3. Make sure that the ICE AUGER is placed inside the SHAVER BOWL on the motor base and that the SECURING NUT is properly locked in place.
4. Remove the LID by first pressing the RELEASE BUTTON located on the back side of the MOTOR BASE, and then by lifting up on the LID.
5. Place frozen ice cubes in the ICE AUGER leaving about 1 inch from the top level of the ICE AUGER. DO NOT OVERFILL.
6. Place a wide mouth cup or snowcone under the ice outlet to catch the shaved ice.
7. Lock the LID onto the MOTOR BASE by first engaging the clips located on the front of the LID and the MOTOR BASE and then by pressing the LID down onto the MOTOR BASE while pressing the RELEASE BUTTON.
8. Plug unit into electrical outlet.
9. Press the ON/OFF button located on the back side of the MOTOR BASE to begin making snow. DO NOT ADD ICE CUBES THROUGH THE TOP OF THE UNIT WHILE THE MACHINE IS RUNNING.
10. Once the unit has finished shaving the ice cubes, press the ON/OFF button again to turn the machine OFF. (After shaving, there will always be a small amount of ice remaining in the machine.)
11. Unplug from the power supply immediately after use.

## OPERATION (CONTINUED)


12. Add syrup to the shaved ice. The ears serve as flavor bottles that hold & dispense flavored syrup.
13. Remove the LID by pressing down on the RELEASE button.
14. Remove the ICE AUGER by turning the SECURING NUT counter-clockwise until free.
15. Gently pull the ICE AUGER out of the MOTOR BASE.
16. Clean all excess ice and water from the unit after use (see cleaning instructions).

### NOTE:

- Occasionally ice may build up and get lodged in chute. If ice is not coming out of the chute gently, shake the unit to ensure that the ice is not frozen together.
- Do not over fill ice auger with ice. Over-filling ice auger may damage your machine.
- Do not add ice while ice auger is churning.
- If ice shaver will not shave ice, turn off machine, unplug unit, remove ice from shaver bowl and try again. If ice shaver will still not shave ice, try using smaller ice cubes.



## CLEANING



### CARE & CLEANING

**CAUTION:** The stainless steel **BLADE** is very sharp—handle carefully. Do not immerse the **MOTOR BASE, CORD** or **PLUG** in water.

1. Make sure that the unit is turned OFF and that the unit is unplugged.
2. Wipe the outside surface of the unit with a damp cloth.
3. Remove the LID by first pressing the **RELEASE BUTTON** located on the back side of the **MOTOR BASE**, and by lifting up on the LID. Clean and dry the inside of the unit.
4. Remove the **ICE AUGER** by turning the **SECURING NUT** counter-clockwise.
5. Gently pull the **ICE AUGER** out of the **MOTOR BASE**.
6. Clean all excess ice and water from the unit with a damp cloth or paper towel.
7. Thoroughly rinse out flavor bottles with hot soapy water.

**NOTE:** Do not wash the parts in your dishwasher.

## RECIPES

### Cool, Easy Favorites For Kids & the Young at Heart

#### **Snow Cones**

Make snow cones the Disney way! Shaved ice is so snowy fine that it absorbs the flavor rather than letting it run to the bottom. Each taste is a flavor sensation! Simply add one or more of our delicious snow cone syrups to create your own favorite flavor. So good!

#### **Slushes**

Place shaved ice into serving cups or glasses. Add just enough snow cone syrup to totally absorb the shaved ice. Add sliced or diced fruit if desired.

#### **Rainbow Slush**

Create this fun, colorful slush by layering snow cone syrups in a tall parfait style glass. For example, add cherry flavor to the bottom layer of ice, then grape flavor to the middle layer and blue raspberry to the top layer of ice. Bright and refreshing!

### **FAVORITE SLUSH VARIATIONS**

#### **Soft Drink Slush**

Fill a glass with shaved ice and add your favorite soda. Cool, simple and so refreshing.

#### **Fruit Juice Slushes**

Add fruit juice such as apple, grape, orange, grapefruit or other favorites to shaved ice. A natural refresher!

## RECIPES (CONTINUED)

### Lemonade Slush

Shaved ice is a perfect addition to lemonades. Try pink lemonade and shaved ice for a fun party drink.

### Fruit Freeze

Place 2 cups shaved ice into your smoothie maker or blender. Add ½ cup fruit and ½ cup fruit juice. Blend until ultra smooth. For a thicker slush, add more shaved ice.

### Tropical Breeze

Combine equal amounts of pineapple, apple and orange juices. Pour over a tall glass of shaved ice and garnish with mint leaves, fruit slice or maraschino cherry. Aloha!

### Orange Smoothie

- 1 can (6 oz.) frozen orange juice
- ¼ cup sugar or juice concentrate sweetener
- 1 can water
- 1 teaspoon vanilla
- 1 can milk
- 2 cups shaved ice

Combine all ingredients in a smoothie maker or blender. Process until smooth. For thicker consistency, add more shaved ice. Serve immediately. Yum!

### Strawberry Smoothie

- ¾ cup milk
- ¼ cup sugar
- 1½ cups fresh or frozen strawberries
- 1 tablespoon lemon juice
- 1 cup of frozen strawberries
- 2 cups shaved milk

## RECIPES (CONTINUED)

### Strawberry Smoothie (Continued)

Shave ice cubes of milk and combine with all ingredients in a smoothie maker or blender. Process until smooth. Stir in slices of strawberries and/or bananas. Terrific!

### Light Chocolate Shake

- 1 cup milk
- ½ tablespoon sugar
- 2 tablespoons cocoa or substitute
- 2 tablespoons creamer
- 2 cups shaved milk

Blend ingredients well, then add shaved ice milk.

Variation: Freeze chocolate milk and shave into cup or serving dish. Great for after school snacks! For chocolate malt, add 2 tablespoons malted milk powder to light chocolate shave above.

## Breakfast & Snack Ideas Light and Luscious

### Sun-Rise Delight

- ½ cup blueberries
- 1 teaspoon sugar
- 1 peach, pitted & sliced
- 1 lime, juiced
- 6 cherries, unstemmed
- 2 cups shaved ice

Place in a chilled breakfast bowl. Add fruit mix gently. Sprinkle with lime juice and sugar.

## RECIPES (CONTINUED)

### Fruit & Orange Cream

- 1 peach, pitted and thin sliced
- $\frac{1}{3}$  cup cream or milk
- 1 teaspoon sugar
- $\frac{1}{2}$  banana, sliced
- 1 cherry, unstemmed for garnish (optional)
- 1 cup orange juice, frozen

Freeze orange juice in ice cube mold. Shave into chilled breakfast bowl. Add peach and banana slices, then pour on cream. Sprinkle on sugar and garnish with a single cherry. You'll wake up with a smile!

### Instant Fruit Freeze

- 1 egg
- $\frac{1}{2}$  cup milk
- 2 tablespoons sugar
- Fruit – choose from selections below
- 1 teaspoon vanilla

Prepare the night before to have ready first thing in the morning. Blend all ingredients well by hand or in a smoothie maker or blender. Pour into ice cube molds and freeze solid. In the morning shave ice mixture and pour in another  $\frac{1}{2}$  cup of milk. Stir and enjoy this creamy fruit freeze!

Fruits – choose one or a combination of the following:

- 1 banana, mashed
- 1 cup peaches (fresh or canned), chopped or mashed
- 1 orange, seeded and mashed
- 1 cup cherries, mashed
- $\frac{3}{4}$  cup berries, mashed (strawberry, raspberry, etc.)
- 1 cup cantaloupe, chopped or mashed

## RECIPES (CONTINUED)

### Pineapple-Grapefruit Ice

- 1 cup fresh grapefruit sections
- $\frac{1}{4}$  cup sugar
- $\frac{1}{4}$  cup water
- 1 cup pineapple chunks
- 2 cups shaved ice

Blend all ingredients except ice until smooth, then pour over shaved ice. If desired stir in more shaved ice. Garnish with maraschino cherries and mint leaves.

### Berry Nice

- 1 cup berries (strawberries, raspberries or blueberries)
- 1 cup cranberry or grape juice, frozen
- 1 teaspoon sugar

Freeze cranberry juice in ice cube mold. Shave into chilled breakfast bowl. Add berries and mix slightly. Sprinkle on sugar. For creamy texture, add  $\frac{1}{3}$  cup cream or milk.

### Tropical Fruit Shake

- 1 cup crushed pineapple, canned and undrained
- 1 tablespoon sugar
- $\frac{1}{4}$  teaspoon almond extract
- $\frac{1}{2}$  cup apricot nectar
- $1\frac{3}{4}$  cup milk, frozen
- $\frac{1}{2}$  cup plain yogurt
- 2 drops yellow food color

Combine all ingredients except ice milk in a smoothie maker or blender and process until smooth. Continue to blend while adding shaved ice milk until the mixture has a thick creamy consistency. Garnish as desired.

## RECIPES (CONTINUED)

### Raspberry Sorbet

- 2 cups fresh raspberries (or blackberries)
- 1 tablespoon lemon juice
- 1 tablespoon orange juice
- ¼ cup sugar
- 2 cups shaved ice
- ½ cup water

Combine raspberries and water in a food processor or blender and puree until smooth. Strain through a fine sieve into mixing bowl. Add remaining ingredients and stir until sugar is dissolved. Pour over shaved ice and enjoy.

### Peach or Pear Ice

- 1 can (16 oz.) peaches or pears
- 2-4 cups shaved ice
- 3 tablespoons lemon juice
- Fruit chunks or slices for garnish (optional)

Puree undrained peaches or pears and lemon juice in a smoothie maker or blender. Pour into glasses over shaved ice. Stir in fruit chunks or garnish on top.

### Honeydew-Lime Sorbet

- 2 cups cubed honeydew melon
- 2 tablespoons sugar or 1 tablespoon honey
- ¼ cup fresh lime juice
- 2-4 cups shaved ice

Puree melon, juice and sweetener in blender until smooth. Pour over shaved ice and garnish with mint leaves or fruit slices.

## RECIPES (CONTINUED)

### Sorbets, Sherbets, Ices

#### Raspberry Velvet

- 1 cup raspberries (fresh or frozen)
- ½ cup heavy cream
- 3 cups cranberry juice
- 2 tablespoons raspberry preserves
- 4 cups shaved ice

Combine all ingredients except ice in a blender or smoothie maker and process until smooth. Continue to blend while adding shaved ice until the mixture has a sherbet-like consistency. Pour into stemmed glasses and garnish with a big red raspberry. Serve immediately.

#### Peach Refresher

- 2 fresh peaches, pared and quartered or 1 (16 oz.) can peaches, drained
- 3 tablespoons maraschino cherry syrup
- 1 (16 oz.) lemon-lime carbonated beverage, cold
- ½ cup cream of coconut
- ¼ cup milk
- 1¼ cup milk, frozen

Combine peaches, cream of coconut, milk and cherry juice in a blender or smoothie maker and process until smooth. Shave 1 ¼ cups of frozen milk blocks and add to blender mixture. Process until smooth. Pour equal amounts of mixture into 4 tall glasses. Slowly pour ½ cup lemon-lime soda into each glass. Garnish as desired. Serve immediately.



## RECIPES (CONTINUED)

### Sparkling Lemon-Lime Sorbet

- ¼ cup fresh lemon juice
- ¼ cup sugar (or substitute)
- ¼ cup fresh lime juice
- 2-4 cups shaved ice
- ½ cup Ginger Ale
- Lemon or lime wedges

Stir all ingredients together except ice until sugar is dissolved. Pour into stemmed glasses over shaved ice and garnish with lemon or lime wedges. Delicious!

### Basic Fruit Sorbet

- ¾ cup fruit, mashed or pureed
- ¼ cup sugar or substitute to taste
- ½ cup cold water
- 2 cups shaved ice

Process fruit, water and sugar in blender or smoothie maker until smooth. Add shaved ice or pour ingredients over shaved ice and stir until blended. Adjust sweetener to taste.

### Grape Escape

- ½ cup Concord grape juice
- 1 tablespoon lime juice
- ½ cup frozen grape juice concentrate
- Ginger Ale or 7-Up
- 2-4 cups shaved ice
- ½ cup fresh pineapple chunks or grape clusters for garnish

Blend ingredients except the ginger ale and shaved ice until smooth. Pour into stemmed glass over shaved ice. Top with ginger ale. Stir and garnish with grape clusters.

## RECIPES (CONTINUED)

### Apple-Cinnamon Sorbet

4 Golden Delicious Apples

$\frac{1}{4}$  teaspoon cinnamon

$\frac{1}{3}$  cup sugar (to taste)

2 cups shaved ice

$\frac{1}{2}$  cup apple juice

$1\frac{1}{2}$  teaspoon lemon juice

Thin apple slices dipped in lemon juice for garnish

Core, pare and shred apples. Puree all ingredients except shaved ice in blender or smoothie maker until smooth. Add shaved ice to blender and continue processing until desired consistency is achieved. Garnish with apple slices.

## WARRANTY

We hope you enjoy the delicious snow cones that you can make with the Disney Ice Shaver from Back To Basics. We have designed this Ice Shaver with you in mind. You will find this unique machine not only easy to use, but fun for the whole family.

Your Disney Ice Shaver is warranted for one year from the date of purchase to be free from mechanical defects in material and workmanship under normal household use. During this period, such defects will be repaired or the product replaced without charge. This warrant does not cover exterior or interior finish or damage caused by misuse, accident or negligence. A purchase receipt or other proof of date for original purchase will be required before warranty service is rendered. Back to Basics Products, Inc.

If a problem with this houseware item develops during or after the warranty period, please contact Back To Basics Products, Inc. for service.

If service is required:

- Send a brief letter explaining the problem. Be sure to include your name, address and phone number.
- For faster service, call customer service at (800) 688-1989 or email [service@btbproducts.com](mailto:service@btbproducts.com).
- Most service problems are resolved by replacing a broken or defective part. If this is not the case, we will give you instructions for returning the unit.





**Please complete and return this product warranty card or register your product online at: [backtobasicsproducts.com](http://backtobasicsproducts.com) within 10 days of purchase.**

**THIS INFORMATION IS FOR INTERNAL USE ONLY**

☐ Mr. ☐ Mrs. ☐ Ms. ☐ Miss **Model: Disney® Ice Shaver**

1. Name \_\_\_\_\_

2. Address \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip Code \_\_\_\_\_

3. E-Mail Address \_\_\_\_\_

4. Age: 18-24 ☐ 25-34 ☐ 35-49 ☐ 50+ ☐

5. Marital Status: ☐ Married ☐ Single

6. Number of Children in the House : 12 yrs and under \_\_\_\_\_ 13-18 yrs \_\_\_\_\_

7. Income: ☐ Below \$25,000 ☐ \$25,000-\$50,000 ☐ \$50,000-\$75,000 ☐ \$75,000+

8. Where was this product purchased? \_\_\_\_\_

9. How did you become aware of this product?

<input type="checkbox"/> Gift	<input type="checkbox"/> Recommendation from friend
<input type="checkbox"/> TV advertisement	<input type="checkbox"/> Saw product in store
<input type="checkbox"/> Print Ad	<input type="checkbox"/> TV shopping program
<input type="checkbox"/> Magazine article	<input type="checkbox"/> Internet
	<input type="checkbox"/> Other _____

10. Check the two most important reasons influencing your purchasing of this Back to Basics product:

<input type="checkbox"/> Gift	<input type="checkbox"/> Recommended by sales person
<input type="checkbox"/> Special offer	<input type="checkbox"/> Recommended by friend
<input type="checkbox"/> Product appearance	<input type="checkbox"/> Prior experience with Back to Basics
<input type="checkbox"/> Ease of operation	<input type="checkbox"/> Back to Basics brand reputation
<input type="checkbox"/> Quality/durability	<input type="checkbox"/> Value for price
<input type="checkbox"/> Product features	<input type="checkbox"/> Product packaging
	<input type="checkbox"/> Other _____

11. Why did you purchase this product?

☐ Purchased as a replacement/upgrade of broken product  
☐ Purchased as secondary product in addition to product(s) already owned  
☐ First product(s) ever owned  
☐ Received as a gift

12. Would you be interested in being contacted via e-mail for promotions, recipes, new product information, etc.?

☐ YES

☐ NO

COMMENT \_\_\_\_\_

Fold here and mail registration card within 10 days of purchase to validate warranty.

---

Place  
Stamp  
Here

BACK TO BASICS PRODUCTS, INC.  
675 West 14600 South  
Bluffdale, UT 84065 USA



For additional operating assistance, please visit our website at [www.backtobasicsproducts.com](http://www.backtobasicsproducts.com) or contact customer service at 1.801.571.7349

Distributed by Back to Basics Products, Inc., Bluffdale UT  
Disney Elements © Disney 2005.

© 2006 Back to Basics Products, Inc., Bluffdale UT 84065  
All rights reserved